



Vyvebroadband.com



We listened...

# your channel guide is coming soon!


The new Vyve HD Guide experience, powered by TiVo®, makes finding exactly what you want to watch fun and easy.



Your HD Set-Top Box will be automatically updated with the Vyve HD Guide, powered by TiVo. Here are the basic operating instructions to make sure you are up to speed with navigating the guide once it's added to your box.

## Grid Guide

To enter the grid guide press the  button.



## Mini Grid Guide

Press the  button on the remote while watching TV to access the Mini Guide.



Use the **Arrow** buttons to browse channel programs without changing the current channel.



Press **OK** button to select and change the channel.



Press the **CH up/down** button to advance one whole page up or down in the channel list.



Press the **Pg up/down** buttons to advance one whole page up or down in the channel list.



Press the **B** button to toggle the channel list to sort between channel name or channel number.



Input a **channel number** on the remote and wait 3 seconds and the grid will then display that channel.




Press the **Exit** or **Guide** buttons to return to live TV.

## TiVo® Info Banner



Press the **Info** or **Arrow** buttons on the remote while watching TV to access the Info Banner.



Press the **CH up/down** buttons to advance one channel up or down with the Info Banner displayed.



Input a **channel number** on the remote and wait 3 seconds and the channel will change to the number.



Press the **Exit** or **Info** or **Left Arrow** buttons to return to live TV.